



Plantronics CS50 Headset System Reset

This guide will demonstrate how to reset your headset.

Written By: Joe



INTRODUCTION

If your headset had been working great but suddenly started producing static or distorted sounds, you may need to reset your headset. Follow these instructions:

Step 1 — Plantronics CS50 Headset System Reset



- Press and hold both the call control button and the listening volume/mute button for five seconds.
- When the talk indicator light blinks, release both buttons.

Step 2



- Press the call control button again.

Step 3



- Unplug the base unit's power source for ten seconds.
- Plug the power source back in.

This document was last generated on 2017-06-19 10:45:38 AM.